



User's Manual

Multi-Format LCD Monitors LVM Series

- LVM-084



TVlogic

Warning

- Always use set voltage.
 - DC 12V 1.5A
- If liquid is spilled on or impacts this product, please disconnect the product immediately and seek professional help before continued use.
- Keep unit disconnected during extended periods of disuse.
- Keep unit in a well-ventilated place to prevent overheating.
- Do not install the product near any heat-generating equipment.
Also, keep the product out of direct sunlight or dusty areas.
- Only clean the product with a noncommercial, mild and neutral detergent.
- When transporting the product, make use of its original packaging for safer carriage.

FCC (Federal Communications Commission)

This equipment has been tested and found to comply with the limits for class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interface when the equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential to correct the interference at his own expense

⚠ Warning!! : Change or modifications not expressly approved by the manufacturer responsible for compliance void the user's authority to operate the equipment.

Disposal of Old Electrical & Electronic Equipment (Applicable in the European Union and other European countries with separate collection systems)



This symbol on the product or on its packing indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequence for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources.

Features

LVM Series units have the following features:

Compatible with varied SDI signals

The product is compatible with varied SDI Signals

- 480i, 576i, 720p, 1080i, 1080p, 1080psF (SDI A, B 2 channel compatible)

Compatible with varied analog signals

The product is compatible with varied analog signals

- Composite, S-Video, Component, RGB, etc.

All-in-one system

Slim and all-in-one type monitor that requires no additional accessories, which provides optimized space utilization.

DC compatible

The product may be powered by normal AC source, but also 12V DC source.

Remote control function

Remote-controlled simply with cable connection without additional peripheral equipment attached to unit.

VGA function built-in

No other product can use common VGA Monitor.


Additional Features

Wide Viewing Angle, Reclocked Active Through OUT (SDI), VESA Mounting Standard, 400:1 contrast ratio, 400cd brightness, OSD user interface, rack mountable.


Name & Function of Each Part

LVM-084

<FRONT>



<REAR>



<FRONT>

· ANALOG INPUT

Used to select desired ANALOG INPUT. A Sub Menu for each analog input connected can be selected.

· SDI INPUT SELECT

Used to select SDI INPUT A or B.

· UNDER SCAN

Used to transfer from OVER SCAN mode to UNDER SCAN mode.
(Compatible up to SD 1:1 SCAN mode.)

· ASPECT

Used to change the monitor ratio on SD signal mode to 16:9.

· MARKER

Used to show MARKER on the screen. The type of marker at work may be selected on the main menu.

· H/V DELAY

Used to observe horizontal sync and vertical sync simultaneously.

· BLUE ONLY / MONO

You may remove R(red) and G(green) from the input signal and play the screen only with B(blue) signal. Button may be pressed twice to change the screen to MONO mode. (This mode uses only luminance value.)

- **MENU**

Used when OSD menu is activated.

- **DOWN/BRIGHT**

Used to navigate menu during OSD menu activation. It may also be used to control the BRIGHT value when the OSD menu is not active.

- **UP/CONTRAST**

Used to navigate the menu during OSD menu activation. It may also be used to control the CONTRAST value when the OSD menu is not active.

- **ENTER**

Used to confirm a chosen value (or mode) during OSD menu activation or inactivation.

- **STANDBY**

Indicates power supply connection and current setting. The lamp is RED when unit is connected to power supply and in standby mode and GREEN during system operation. In case of sudden loss of power unit retains last setting.

- **TALLY**

LED indicating monitors current status

<REAR>

· REMOTE (RJ-45)

Connection for remote control of monitor.

· VGA IN / FACTORY PGM

Input connection for VGA mode and input connector for FACTORY PGM allowing for firmware updates.

· CVBS1/Y/G/S-Y (BNC)

Signal input terminal used for COMPOSITE1, S-VIDEO Y, COMPONENT Y, RGB G signals.

· CVSBS2/Pb/B (BNC)

Signal input terminal used for COMPOSITE2, RGB B, COMPONENT Pb signals.

· CVSBS3/Pr/R/S-C (BNC)

Signal input terminal used for COMPOSITE3, S-VIDEO C, COMPONENT Pr, RGB R signals.

· SDI-IN (BNC)

SDI signal input terminals that provide A and B inputs.

· SDI-OUT (BNC)

SDI signal output terminal used for SDI output.

· DC 12V 1.5A IN (XLR, Male)

Used to supply DC power; 12V

· COOLING FAN

In order to prevent overheating, it affixed cooling fan.

· CHROMA/PHASE

Used to change the CHROMINANCE and PHASE values. Pressing the button once will activate the CHROMA mode, pressing the button twice activates PHASE mode. (PHASE may be used only with COMPOSITE and S-VIDEO on ANALOG mode.)

Information

Input VIDEO connection method

Connector	Composite	Component		S-Video
1	CVBS1	Y	G	Y
2	CVBS2	Pb	B	No Con.
3	CVBS3	Pr	R	C

Warning!!

Before using this unit make certain to connect the power supply before connecting a signal to any of the inputs. The unit may not function properly if a signal is connected before the power supply is connected. As an example: the unit will not function properly when using an RCA-to-BNC (BNC-to-RCA) connection if the signal is connected to the input before the unit is connected to the power supply.

Information

The UNDER SCAN and the MARKER button are including the ASPECT and H/V DELAY function. When using, the UNDER SCAN and MARKER function pay attention become first of all.

Menu Organization & Adjustment

The product may be controlled and set system-wide through an OSD.

1) Menu Organization

Below is the organization of the product's menu.



2) Menu Control

You may control various functions using MENU, UP/DOWN and ENTER buttons on the bottom-front of the monitor.

3) Menu Control Sequence

Menu control sequence follows the order below

1. Press MENU button to bring up the OSD menu.
2. Highlight the desired item with the UP/DOWN button.

- LVM-084
3. Press ENTER to select an item, make sure the item turns red and then change the set value.
 4. Select the desired new value with the UP/DOWN button.
 5. Press ENTER to save the new value (verified by highlighted field returning to default black color).
 6. Press MENU once again to remove OSD menu from the screen.

Menu Contents

Below is the description of each function of the menu.

· **BRIGHT**

This item controls the degree of brightness between MAX(50) and MIN (-50) range.

· **CONTRAST**

This item controls the contrast ratio between MAX(50) and MIN(-50).

· **COLOR**

This item controls COLOR TEMP. and is basically compatible with 5000K, 5600K, 6500K, 9300K and USER modes. On USER mode, the user may select among R, G and B values. By COLOR COPY function you can copy wanted setting values and just adjust the only value you want change.

· **PHASE**

This item controls PHASE value (Tone) between MAX(50) and MIN(-50). However, it is only available on COMPOSITE and S-VIDEO in ANALOG mode.

· **CHROMA**

This item controls saturation between MAX(50) and MIN(-50).

· **APERTURE**

This item controls the picture sharpness. Sharpness select MIN(-4) and MAX(15).

· **MARKER**

This selects the marker type when the MARKER is displayed on the screen. MARKER may only be activated by pressing the MARKER button on the front of the monitor.

Compatible MARKER types are as follows:

MODE	MARKER CLASS
HD	4:3, 4:3 ON AIR
SD 16:9	15:9, 14:9, 13:9 1.85:1, 2.35:1 1.85:1 & 4:3
SD 4:3	16:9

· **CENTER MARKER**

This item displays the CENTER MARKER on the screen. This function operates only after activating the MARKER function by pressing the MARKER button on the front of the monitor.

· **SAFETY AREA**

This item controls the size of the SAFETY AREA between 80%, 88%, 90% and 93%.

· **MARKER MAT**

This item darkens the area on the outside of MARKER setting area. The degree of darkness is between OFF (0) and (7). The higher the number, the darker MARKER border becomes.

· **MARKER COLOR**

This item controls the color when MARKER is generated. Settable colors are white, gray, black, red, green and blue.

· **NTSC SETUP**

This item sets IRE value in NTSC mode between 0 IRE and 7.5 IRE.

· REMOTE SETUP

This product is compatible with exterior REMOTE CONTROL. The user may access the remote setup menu from here.

· SYSTEM

You can use the SYSTEM menu to confirm the hours of use on the product or additional product information.

· SET DEFAULTS

You can use SET DEFAULTS menu to initialize the values of BRIGHT, CONTRAST, PHASE and CHROMA of the monitor.

Other Functions

1) ANALOG Mode Usage

This product is capable of processing all input signals usable in ANALOG mode. The ANALOG input settings are as follows:

1. Press ANALOG button on the front of the product and activate the menu below.



2. Highlight the value you desire by using the UP/DOWN button and press the MENU button to confirm your selection. From this point the OSD menu operates identically to the MENU operations discussed above.

Warning!!

When using ANALOG mode, always check the input method and modify the setting as needed for optimized output results.


2) COLOR USER Mode Usage

This product provides COLOR adjust mode. User can set the color as he wanted or select default color temp. COLOR MODE may be used in the following manner.

1. Press MENU to call up the OSD menu.



2. Select COLOR among MENU and you will see below OSD MENU.



3. On COLOR TEMP item, Press ENTER and select one of 5000K, 5600K, 6500K, 9300K and USER using UP/DOWN button and press ENTER. If you selected USER mode, you can set the value RED, GREEN, BLUE GAIN and BIAS.

Gain controls adjusting color temp and BIAS controls adjusting color level.

4. After the selected character of value turns to red, adjusting the value with the UP/DOWN button, press MENU again to save the selected value. The value should be within the ranges MAX(50) and MIN(-50).

5. COLOR COPY mode can be used only in USER MODE. If user wants to change only a specific value from standard mode, it will be a useful function. If the color temp. is 6500K, and user wants to change only the blue gain value, the user can COLOR COPY function as following steps;

- ① Select USER MODE among menus of COLOR TEMP, and set the COLOR COPY mode set 6500K.
- ② Select BLUE GAIN with UP/DOWN button and press enter.
- ③ Control BLUE GAIN and press ENTER.

3) REMOTE Mode Usage

This product provides a REMOTE CONTROL mode. The user may connect the RJ-45 jack to the REMOTE terminal on the rear of the unit and designate a function for each pin. The method for designating functions for pins is as follows:

1. Press MENU to call up the OSD menu.



2. Select REMOTE SETUP on MENU.
3. The REMOTE SETUP menu will be activated.


REMOTE SETUP	
PIN 1	ANALOG CHANNEL
PIN 2	DIGITAL A CHANNEL
PIN 3	DIGITAL B CHANNEL
PIN 4	TALLY R
PIN 5	TALLY G
PIN 6	UNDER SCAN
PIN 7	POWER ON
PIN 8	GND

The user may designate functions for PIN1 ~ PIN 6. PIN7 is for POWER ON/OFF use only. The selectable functions are as follows:

Menu Classification	Settable Values
PIN 1~6	NONE, ANALOG CHANNEL DIGITAL A,B CHANNEL TALLY R,G , BLUE ONLY SD 1:1 SCAN, UNDER SCAN ASPECT, H/V DELAY 16:9,15:9,14:9,13:9 MARKER 4:3, 4:3 ON AIR MARKER 1.85:1, 2.35:1 MARKER 1.85:1&4:3 MARKER CENTER MARKER SAFETY AREA 80%, 88% SAFETY AREA 90%, 93%

4. On the pin to be used, set the function you desire with the ENTER button and UP/DOWN button. The method of setting the values is the same as that for the MENU function discussed earlier.

Pin number designation is depicted below. Pin #8 should be left as the RJ-45 GND.



4) COMPUTER Mode

This product supports VGA mode. If user wants this model to use Computer monitor, select this mode. This mode usage is as the following.

1. Press the ANALOG button to bring up the OSD menu. Select COMPUTER and press the MENU button.



2. This mode's OSD MENU is different than the other OSD MENU.
This mode is controlled by DOT PHASE, H SHIFT and V SHIFT. The function control methods are described below.



· **DOT PHASE**

Use this item for tuning the screen. Controls DOT PHASE value between MAX(31) and MIN(0).

· **H SHIFT**

Use this item to move the entire screen to the left or right. Controls H SHIFT value between MAX(63) and MIN(-64).

· **V SHIFT**

Use this item to move the entire screen up or down . Controls V SHIFT value between MAX(7) and MIN(-8).

3. COMPUTER mode is support below resolution and frequency.

Resolution	Frequency
640 × 480	60Hz, 75Hz, 85Hz
800 × 600	60Hz, 72Hz, 75Hz, 85Hz
1024 × 768	60Hz, 70Hz, 75Hz, 85Hz
1280 × 768	60Hz
1280 × 1024	60Hz (Sub-sampling mode)
720 × 400	70Hz

Additional Remarks

1. LVM-084 added BACK LIGHT control item in main OSD.



· BACK LIGHT

This item controls LCD Panel's brightness. The value should be within range between MIN(0) and MAX(40).

Product Specification

Below is the product specification

LVM-084		
Input	1 x D-SUB	VGA IN
	3 x BNC	Analog Input
	2 x BNC	SDI 2 Channel Input
Output	1 x BNC	Selected SDI Channel (Active Through Out)
Input Signal	Analog	Composite / S-Video / Component / RGB
	HD-SDI	1.485Gbps
	SD-SDI	270Mbps
	VGA	640 X 480 / 800 X 600 / 1024 X 768 / 1280 X 768 / 1280 X 1024* / 720 X 400
Analog Input Spec	Composite	1.0Vpp (With Sync)
	S-Video	1.0Vpp (Y With Sync), 0.286 Vpp (C)
	Component	1.0Vpp (Y With Sync), 0.7 Vpp (Pb,Pr)
	RGB	1.0Vpp (G With Sync), 0.7 Vpp (B,R)
SDI Input Signal Formats	SMPTE-274M	1080i (60 / 59.94 / 50)
		1080p (30 / 29.97 / 25 / 24 / 24sF / 23.98 / 23.98sF)
	SMPTE-296M	720p (60 / 59.94 / 50)
	SMPTE-260M	1035i (60 / 59.94)
	SMPTE-125M	480i (59.94)
	ITU-R BT.656	576i (50)
LCD	Size	8.4"
	Resolution	1024 x 768 (4:3)
	Dot Pitch	0.165 mm
	Color	16.7M(true), 24bit
	Viewing Angle (Typical)	H : 170 degrees V : 170 degrees
	Luminance of White	400cd (center)
	Contrast	400:1
	Display Area	170 x 128 mm
Power		12V DC
Power Consumption (Approx.)		16 Watts (DC)
Operating Temperature		0 °C to 40 °C (32 °F to 104 °F)
Storage Temperature		-10 °C to +50 °C (14 °F to 122 °F)
Main Body Dimensions (W x H x D)		215 x 177 x 59
Main Body Dimensions (with stand)		-
Weight		2.1Kg
Accessory		DC Power Adapter AC Power Cord
Option		V-mount 19" Rack Mountable Kit (4U Dual Monitor) Soft Bag (Hood)

Above specifications may be changed without notice.

* VGA 1280 X 1024 mode is sub-sampling mode.





optional accessory



Hood-&-Handle 8.4" 17"



Tripod Head 7" 8.4"



Carrying Case 17" 23" 24" 40" 46" 57"



V-Mount 7" 8.4" 17"



Rack-Mountable Kit 7" 8.4" 17" 23"

Developed by

TVlogic

For more information please visit : www.tvlogic.co.kr

World Meridian Venture Center II #610, 426-5 Gasan-Dong , Geumcheon-gu, Seoul, 153-803, Korea

TEL : +82-2-2025-8191 FAX : +82-2-2025-8192 E-mail : support@tvlogic.co.kr